1	Before driving	1-6.	Refueling Opening the fuel tank cap	
1-1.	Hybrid system2	1-7.	Anti-theft system	62
	Hybrid system2		Hybrid vehicle immobilizer system	62
1-2.	Key information12		Alarm	64
	Keys 12		Theft prevention labels (U.S.A.)	66
1-3.	1 3, 3	1 Ω	Safety information	67
	the doors and trunk14	1-0.	•	
	Smart access system with		Correct driving posture	
	push-button start14		SRS airbags	
	Wireless remote control23		Child restraint systems	
	Doors26		Installing child restraints	83
	Trunk 30			
1-4.	Adjustable components 34	2	When driving	
	Front seats			
	Driving position memory	2-1.	Driving procedures	94
	system36		Driving the vehicle	94
	Head restraints39		Starting the hybrid system	101
	Seat belts 42		Transmission	104
	Steering wheel48		Turn signal lever	108
	Inside rear view mirror49		Parking brake	109
	Outside rear view mirrors 50			
		2-2.	Instrument cluster	110
1-5.	Opening and closing the		Gauges and meters	110
	windows and moon roof 52		Indicators and warning lights	114
	Power windows52		Multi-information display	117
	Moon roof55			

2-3.	Operating the lights and	
	windshield wipers 120	
	Headlight switch	
	Fog light switch 123	
	Windshield wipers and	
	washer 124	
	Headlight cleaner switch 126	
2-4.	Using other driving	
	systems 127	
	Cruise control127	
	Dynamic radar cruise	
	control 130	
	Intuitive parking assist 139	
	$Rear\ view\ monitor\ system\\ 158$	
	AVS (Adaptive Variable	
	Suspension System)161	
	Driving assist systems 162	
	PCS (Pre-Collision	
	System) 167	
2-5.	Driving information170	
	Cargo and luggage 170	
	Vehicle load limits	
	Winter driving tips 174	
	Trailer towing 179	
	Dinghy towing 180	

## Interior features

3-1.	Using the touch screen 182
	Touch screen 182
	Setting the touch screen 185
3-2	Using the air conditioning
J-2.	system and defogger191
	Automatic air conditioning system
	Rear window and outside rear view mirror defoggers
3-3.	Using the audio system 200
	Audio system type 200
	Using the radio 203
	Using the cassette player 212
	Using the CD player 216
	Playing MP3 and WMA discs224
	Using the DVD player
	Playing DVD video/audio 235
	Playing video CD248
	DVD player and DVD video disc information
	Optimal use of the audio/video system
	Using the steering switches

3-4.	Using the hands-free		N4 :
	system263	4	Mair
	Hands-free system	4-1.	<b>Mai</b> Clea
	Setting the hands-free system		vel Clea vel
3-5.	Using the interior lights 307	7	VCI
	Interior lights list307	4-2	. Mai
3-6.	Using the storage features 311 List of storage features 311		Maii Ger Emis
3-7.	Other interior features 317	,	pro
	Sun visors	13	. Do-i
	Clock	)	ma
	Outside temperature display		Do-i pre Hoo
	Cigarette lighter 322		Posi
	Power outlet	3	Engi Tires Tire
	ventilators	)	Whe
	Armrest	3	Airo
	Rear sunshade 329	)	Elec
	Floor mats	1	Che
	Trunk features		fus Hea
	Garage door opener		Ligh

## 4 Maintenance and care

4-1.	Maintenance and care	. 344
	Cleaning and protecting the vehicle exterior	. 344
	Cleaning and protecting the vehicle interior	. 346
4-2.	Maintenance	. 349
	Maintenance requirements	. 349
	General maintenance	351
	Emission inspection and maintenance (I/M)	
	programs	. 354
4-3.	Do-it-yourself	
	maintenance	. 355
	Do-it-yourself service precautions	355
	Hood	
	Positioning the jack	
	Engine compartment	361
	Tires	. 375
	Tire inflation pressure	385
	Wheels	389
	Air conditioning filter	391
	Electronic key battery	. 393
	Checking and replacing fuses	395
	Headlight aim	411
	Light hulbs	

5-1.	Essential information	. 420
	If your vehicle needs to be towed	420
	If you think something is wrong	427
	Event data recorder	
5-2.	Steps to take in an	
	emergency	430
	If a warning light turns on or a warning buzzer sounds	430
	If a warning message is displayed	436
	If you have a flat tire (Vehicles with run-flat tires)	455
	If you have a flat tire (Vehicles with standard tires)	456
	If the hybrid system will not start	466
	If the shift lever cannot be shifted from P	467
	If you lose your keys	468
	When the electronic key battery is discharged	469
	If the 12 volt battery is discharged	471
	If your vehicle overheats	475
	If the vehicle becomes	
	stuck	478

When trouble arises

## 6 Vehicle specifications

6-1.	Specifications	480
	Maintenance data	480
	Fuel information	489
	Tire information	492
<i>,</i> 0	<b>2</b>	<b>500</b>
6-2.	Customization	500
	Customizable features	500
63	Initialization	505
0-3.	initialization	505
	Items to initialize	505
7 F	For US owners	
	Reporting safety defects for	

## Index

What to do if	518

Alphabetical index...... 510

U.S.A. owners...... 508